コンパクトディスク コンパクトプレーヤー

取扱説明書/Operating Instructions

お買い上げいただきありがとうございます。

電気製品は安全のための注意事項を守らないと、 火災や人身事故になることがあります。

この取扱説明書と別冊の「安全のために」をよくお読みのうえ、製品 を安全にお使いください。お読みになったあとは、いつでも見られる ところに必ず保管してください。



D-E525

Sony Corporation © 1999 Printed in Malaysia

保証書とアフターサービス

- この製品には保証書が添付されていますので、お買い上げの際お受け取りください。 • 所定事項の記入および記載内容をお確かめのうえ、大切に保存してください。 ●保証期間は、お買い上げ日より1年間です。

アフターサービス

調子が悪いときはまずチェックを この説明書をもう一度ご覧になってお調べくださ

それでも具合が悪いときはサービスへ お買い上げ店、または添付の「サービス窓口• ご相談窓口のご案内」にあるお近くのソニーサービス窓口にご相談ください。 保証期間中の修理は 保証書の記載内容に基づいて修理させていただきます。詳しく は保証書をご覧ください。

保証期間経過後の修理は 修理によって機能が維持できる場合は、ご要望により有料 修理させていただきます。

部品の保有期間について 当社では、CDコンパクトプレーヤーの補修用性能部品(製品の機能を維持するために 必要な部品)を、製造打ち切り後最低8年間保有しています。この部品保有期間を修理 可能の期間とさせていただきます。保有期間が経過した後も、故障箇所によっては修 理可能の場合がありますので、お買い上げ店か、サービス窓口にご相談ください。

ワールドモデルをお買い上げのお客様へ

ワールドモデルとは

日本でも海外でも使用できるように海外、国内の電気事情(電源電圧AC100~ 240 V)に合わせたACパワーアダプターが付属されているモデルです。

海外での保証とアフターサービスについて

●保証期間は、日本国内ではお買い上げ日より1年間、海外では90日です。

•海外での修理やアフターサービスについてご不明な点は、保証書に記載の海外 ソニーサービス特約店にお問い合わせください。

ACプラグアダプターについて

ACパワーアダプターがコンセントと合わない場合は付属のACプラグアダプター をお使いください。


ソニー株式会社 〒141-0001 東京都品川区北品川6-7-35 | | お問い合わせはお客様ご相談センターへ




CDを聞く/Playing a CD right away! A

付属のACパワーアダプターを使ってCDを聞いてみましょう。 充電式電池、乾電池(裏面の「電源」参照)や車のバッテリーで聞くことも

1 つなぐ




2 CDを入れる



③ふたを閉める。

本体で操作するには

3 聞く




②音量を

★IIボタンを

演奏を止めるには、■ボタンを押します。

リモコンを使うには リモコンのⅠ◀◀-▶Ⅱ-▶▶Ⅰ部はジョグレ バーになっています。矢印の方向に押し たり、動かしたりすると、それぞれの操 作が始まります。



前の曲、さらに前の曲を ◄◄側に繰り返し

さらに先の曲を頭出し ▶▶┃側に繰り返し

次の曲を頭出しする ▶▶Ⅰ側に1度

を使って行なうこともできます。

CDを取り出すには

うからつまみあげます。

中心の黒い部分を押さえながら、端のほ

リモコン操作で音量を調節す

まずリモコン側のVOL(volume)つまみを

MAXに合わせ、本体のVOLUMEつまみで

リモコンがMAXのときの音量を決めます。

• ▶IIボタンを押すと(RESUMEスイッチ

がOFFのとき)、総曲数と総演奏時間が

• 演奏中は、演奏中の曲番号とその経過

• 曲間には、次の曲が始まるまでの時間

• 一時停止中は、止まった時点の表示が

• 演奏面に手を触れないように持ってく

• 紙やテープを表面に貼らないでください。

の中に放置しないでください。

• 直射日光があたるところなど高温の場

所や、直射日光下で窓を閉め切った車

CDの取り扱いについて

表示窓について

約2秒間出ます。

時間が出ます。

が出ます。

点滅します。

早戻しする

(サーチ機能)

(サーチ機能)

押す		H4 ↓ ►>	
操作	リモコンでの操作		
一時停止する	ジョグレバーの ▶Ⅱ を押す		
一時停止を解除する	ジョグレバーの ▶Ⅱ を 押す	P MODE	
今聞いている曲を頭出 しする(AMS*機能)	I◀◀側に1度 動かす。**	RPT/E	ENT

きます。

全曲を繰り返すには

演奏中にRPT (repeat)/ENT (enter)ボタ ン(本体ではREPEAT/ENTERボタン)を 押します。 「♀」が出ます。

▶いろいろな聞きかた

繰り返し聞く

(リピート演奏) B

通常の演奏や、イントロプログラム演奏、

シャッフル演奏、プログラム演奏を繰り返

し聞けます。1曲だけでも繰り返し演奏で



リピート演奏をやめるには、もう1度RPT/ ENT ボタンを押します。

1曲だけを繰り返すには **1** 繰り返したい曲の演奏中にRPT/ENT

ÚS 0 1: 17

2 「1」が出るまでP (play) MODEボ

タン(本体ではPLAY MODEボタン)

*AMSはAutomatic Music Sensorの略で す。曲の頭を探す機能です。 ボタンを押す。 これらの操作は、演奏中にも一時停止中に 「ち」が出ます。

RPT/ENTボタン(本体ではREPEAT/ENTER ボタン)を押して「C→」を表示してから、▶▶ で最後の曲まで頭出しまたは早送りし続ける と1曲目に戻ります。また、▶● で1曲目まで 頭出しまたは早戻しし続けると最後の曲にな

◄◀側に押したままに

▶■側に押したまま

にする。

上の表の操作は、本体の同じなまえのボタン




を繰り返し押す。

他の曲を繰り返すにはジョグレバーを▶◀ 側または▶▶側に動かします。

リピート演奏をやめるには、もう1度RPT/ ENT ボタンを押します。

聞きたい曲だけを聞く (イントロプログラム演奏) [C]

曲の最初の15秒をひと通り聞きながら曲 を選び、選んだ曲だけを聞けます。



1 演奏中に「INTRO PGM」が出るま でP MODEボタンを繰り返し押

> ゆっくり点滅 **0** 1 00:05

2 ジョグレバーの**▶**Ⅱを押す。 各曲の最初の15秒を次々に演奏します 「INTRO PGM」は速く点滅します。

3 聞きたい曲になったらRPT/ENTボ 曲が登録されます。聞きたくないとき は次の曲に移るまで待つか、ジョグレ

バーを▶▶●側に動かします。

最後の曲の演奏が終わると、「INTRO PGM」の点滅が止まり、登録した曲だけが 自動的に演奏されます。

最後の曲までいかずに登録を終了するに は、ジョグレバーの▶⊪を押します。登録 した曲が演奏されます。


タンを押す。

■ボタンを押すと、登録した曲順が消えて しまいます。消したくないときは、本体裏 面のRESUMEスイッチをONに合わせて ください。

イントロプログラム演奏をやめるには、演 奏モードの表示が消えるまでP MODEボ タンを繰り返し押します。

順不同に聞く (シャッフル演奏) D

全曲を順不同に聞けます。



演奏中に「SHUF」が出るまで、 P MODEボタンを繰り返し押す。 次の曲から順不同で全曲を1回演奏します。




シャッフル演奏をやめるには、演奏モード の表示が消えるまで、P MODEボタンを 繰り返し押します。

・シャッフル演奏中は、ジョグレバーを◄◄側に 動かしても前の曲には戻りません。

好きな順に聞く (プログラム演奏) 区

最大22曲まで好きな順に聞けます。



1 演奏中に「RMS*」が点滅するまで、 P MODEボタンを繰り返し押す。




2 ジョグレバーを**!◄**¶または**▶**•¶ に動かして曲番を選ぶ。 曲番と演奏順が出ます。



- **3** RPT/ENTボタンを押す。
- 4 2、3を繰り返して好きな曲順を選ぶ

■ボタンを押すと、登録した曲順が消えて 面のRESUMEスイッチをONに合わせて ください。

プログラム演奏をやめるには、演奏モード



RPT/ENTボタンを押すたびに曲番と演奏

ESP(Electronic Shock Protection)機 能はCDのデータを半導体メモリーに貯え ておくことにより、 音飛びを防ぎます。 ESP²は、従来のESP機能よりメモリーに 貯える機能がすぐれ、より音飛びに強くな っています。



05 o i: 17³⁹⁹

ESP機能を解除するには、もう一度ESPボ タンを押します。

- •次のような場合、ノイズが出たり、音が飛んだりす
- ― 汚れや傷のあるディスクを聞いているとき 一特殊な信号が入ったテストディスクなどを聞 いているとき
- •演奏中にESP機能を切り換えると、少しの間 音がとぎれます。
- は働きません。




- **5** ジョグレバーの**▶**Ⅲを押す。 「RMS」の点滅が止まり、選んだ順に 演奏が始まります。

しまいます。消したくないときは、本体裏

の表示が消えるまで、P MODFボタンを

プログラムした曲順を確認するには プログラム中 5の操作の前にRPT/ ENTボタンを押しま



順が表示されます。

•22曲をプログラムした後さらに曲を選ぶと、最 初にプログラムした内容が消えて、新しい曲が プログラムされます。

いろいろな機能を使う

音飛びを防ぐには (ESP²) F

移動中、歩行中や車の中など振動の多いと ころで聞くときは、この機能を使ってくだ さい。



•強い衝撃が加わると演奏が停止することがあり

- ることがあります。
- —本機に連続的に衝撃が加わっているとき

・光デジタルケーブルをお使いの場合はESP機能



SOUNDボタンを押して、「MB (Mega

音楽に合わせて、重厚で迫力のある音で演

低音を強調するには

(SOUND機能) G

Bass)」または「GRV (Groove)」を選びま 「GRV」のほうがより低音が強調されます。 RESUMEスイッチをONに合わせます。

ご注意 音がひずむときは、音量を下げてください。

誤操作を防ぐには (ホールド機能) H 本機をカバンに入れているときなど、誤って ボタンが押されるのを防げます。(リモコンで 操作することはできます。)

> 動作の確認音を止めるには 動作確認のためのピッという音を鳴らない ようにできます。

> > 本体電源(ACパワーアダプター、充電式電 池、乾電池)をはずします。本体の■ボタン を押しながら、再び電源を接続します。 再び確認音が鳴るようにするには、本体電 源をはずし、■ボタンを押さずに本体電源 を接続します。

止めたところからCDを聞くには

通常は演奏を止めると、次は1曲目から演

奏されますが、リジューム機能を使うと、

(000)

リジューム機能を解除するには、

の1曲目から演奏が始まります。

RESUMEスイッチをOFFに合わせます。

•リジューム機能をONにしていても、ふたを開

けると最後に止めたところの記憶が消え、CD

•リジューム演奏は、土約30秒の誤差が出ること

最後に止めたところから演奏されます。

(リジューム機能) J

ホールド機能を解除するには、HOLDス イッチを矢印と反対の方向へ動かします。

HOLDスイッチを矢印の方向へ動かします。

操作ボタンを押しても、「Hold」が出て動

 $(\circ\circ\circ)$

NORM LIMIT

AVLSスイッチをLIMITに合わせます。

•SOUND機能とAVLSを同時に使うと、音がひ

ずむことがあります。その場合は音量を下げて


「AVLS」が出ます。

作しません。

にします。

ステレオ機器につなく 音もれを抑え耳にやさしい音で 聞くには (AVLS) I

オートマチック ボリューム リミッター AVLS(Automatic Volume Limiter 他のステレオ機器でCDを聞いたり、テー プやミニディスクに録音できます。詳しく System)は耳にやさしい音にするため は、接続する機器の取扱説明書をご覧くだ に、音量がある一定以上に上がらないよう さい。接続する機器の電源を必ず切ってか ら接続してください。



ステレオシステム、

ポータブルミニ ダーやDATデッ

> *LINE INやREC INジャックのない機器をつな ぐときは、別売りの接続コードRK-G134を使っ てMICジャックに接続します。 **角型ジャック付き機器の場合はPOC-5AB(別

売り)をお使いください。

•CDを聞く前に、つないだ機器の音量を下げて ください。思わぬ大音量が出て、スピーカーを

破損するおそれがあります。 •「ピッ」という操作音はLINE OUT (OPTICAL)ジャックからは出力されません。

•LINE OUT (OPTICAL)ジャックにケーブルを 接続しているときには、つないだ機器で音量を 調節してください。 •ブランクサーチ(無音部検出)機能のあるカセッ

トデッキなどで録音するときは、ESP機能を切 ってください。ブランクサーチ機能が働かなく かります •録音するときは、ACパワーアダプターをお使 いください。充電式電池や乾電池を使うと録音

途中で電池を消耗することがあります。 接続コードをお使いの場合 •SOUND機能は働きません

光デジタルケーブルをお使いの場合

MD、DAT等への録音は、下記のように 行なってください。 1 CD側の▶IIボタンを押す。(PLAYす

2 もう一度▶Ⅱボタンを押す。(一時停止

3 ◄◀または▶▶|ボタンを押して、録音し たい曲にする。 4 MD、DAT等の録音ボタンを押す。

5 CD側の▶IIボタンを押して一時停止を 解除する。

光デジタルケーブルの接続はCDプレーヤーが

停止している状態で行ってください。 •CD側を一時停止せずに録音を行うと、ディス クによっては1曲目の曲番が、正しく録音され 15 VOLUME (音量調節)つまみ ないことがあります。 ◆SOUND機能は೧/REMOTEジャックからの出 力には働きますが、LINE OUT (OPTICAL)か

車の中で聞くには 本機をカーカセットデッキにつなぐと、車 の中でCDを聞くことができます。

らの出力には働きません。

•ESP機能は働きません。

本機ではカーマウントプレートはお使いに なれません。車の中でお聞きになるとき は、運転の妨げにならない安全な場所に しっかりと固定してください。

本機をカーカセットデッキにつなぐには、 次のカーアクセサリーが必要です。

• カーバッテリーコード DCC-E245と カーコネクティングパック CPA-8/ $CPA_{-}9$

くわしくは各製品の取扱説明書をご覧くだ

•本機をダッシュボードの上に置かないでくださ •本機を直射日光の当たる車の中に置かないでく

•雑音を減らすためソニーのカーコネクティング パックを使うことをおすすめします。 カーバッテリーコードは、別売りアクセサリー に記載されているものをお使いください。これ 以外のものをお使いになると、発煙・発火なら びに故障の原因になります。

イグニッション連動オフ機能 (カーバッテリーコードでお使いの場合) 充電式電池や乾電池が入っていても、車の エンジンを切る(イグニッションキーを OFFにする)と、本機は自動的に停止状態 になります。(車種によってはこの機能が 働かないことがあります。)

あなたが録音したものは、個人として 楽しむなどのほかは、著作権上、権利 者に無断で使用できません。

各部のなまえ |L|

2 PLAY MODEボタン 3 ESP*ボタン

4 I◀◀/▶►I(AMS**/サーチ)ボタン 5 HOLDスイッチ

6 OPENつまみ 7 ■ (停止)ボタン

| 8 | ▶ | | (演奏 / 一時停止)ボタン 9 REPEAT/ENTERボタン **10** SOUNDボタン


12 RESUMEスイッチ(裏面) 13 DC IN 4.5V (外部電源入力)ジャック 「14 LINE OUT(OPTICAL)(ライン出力 (光デジタル))ジャック

11 AVLS***(快適音量)スイッチ(裏面)

16 C/REMOTE(ヘッドホン/ リモコン) ジャック *ESPはElectronic Shock Protectionの略です。

AMSはAutomatic Music Sensorの略です 曲の頭出しをして選曲する方法です。 *AVLSILAutomatic Volume Limit Systemの略です。

リモコン (表面)



1 HOLDAイッチ 2 表示窓

3 ■ (停止)ボタン 4 ジョグレバー

▶Ⅲ:演奏/一時停止 5 VOL (volume) (音量調節)つまみ

6 RPT (repeat)/ENT (enter)ボタン 7 P (play) MODEボタン

8 SOUNDボタン **9** ESPボタン

10 クリップ

回して角度を変えることができます。


裏面につづく**→**

充電してください。 充電式電池はNC-DMAA(付属)または NH-DM2AA(別売り)をお使いくださ い。これ以外の充電式電池は使えません。


1 電池入れのふたを開ける。



2 充電式電池NC-DMAA2本を電池入 れの⊕⊝の表示に合わせて入れ、ふ たを閉める。




3 下の絵のように付属のACパワーアダ プターをつなぎ、約4時間 充電する 充電中は「CHG」が出ます。 (すでに充電が完了している場合は、 「CHG」と 🕶 が点滅します。)



4 充電し終わって「CHG」が消えた ら、ACパワーアダプターをはず

充電式電池を取り出すには 電池入れのふたの裏側の絵、または下の絵 に合わせて、正しく取り出してください。



充電式電池が消耗すると□のが表示され、 その後「Lo bdtt」が表示されます。充電 式電池を充電してください。

充電式電池を長持ちさせるために、充電式 電池は消耗してから充電してください。 充電式電池を持ち運ぶときは

バッテリーキャリングケースをお使いくだ 金属性のものと一緒に携帯するとショート

して、発熱、発火する場合があります。

•充電時間は充電式電池の使用状態により異なり

•初めて充電するときや長時間使用しなかった後

では、充電しても通常の持続時間より短いこと

があります。何回か充放電をすると通常の状態

• 充雷後、常温で使える時間の半分くらいで雷池

がなくなってしまうときは、新しい充電式電池

NC-DMAAと交換してください。これ以外の

充電式電池と同じ方法で正しく入れてくだ

1 ACパワーアダプターを取りはず

し、電池入れのふたを開ける。

に戻ります。

充電式電池は使えません。

乾電池で使う N

使用上のご注意


▶その他

- たると危険です。絶対にプレーヤーを分 解したりしないでください。
- 万一、異物が中に入ったときは、電源を 切り、お買い上げ店またはソニーサービ ス窓口にご相談ください。 • DC IN 4.5 V(外部電源)ジャックには異
- 物を入れないでください。

電源について

• 本機を使用しないときは、すべての電源 をはずしておいてください。

2 単3形アルカリ乾電池2本(別売り) を電池入れの⊕⊝の表示に合わせて 入れ、ふたを閉める。



•本機には、マンガン電池はお使いになれません。

乾電池を取り出すには 充電式電池と同じ方法で正しく取り出して ください。

電池交換の目安

電池が消耗すると□■が表示され、その後 「Lo bdtt」が表示されます。2本とも新 しい乾電池と交換してください。

乾電池の取り扱いについて 液漏れや破裂を防ぐため次のことをお守りくだ 新しいものと古いもの、または違う種類のもの を混用しないでください。

充電しないでください。 •長い間使わないときは、出しておいてください。 ●万一、液漏れしたときは、よく拭き取ってか ら、新しい電池に入れ換えてください。

電池の持続時間(水平に置き、振動の ない状態で演奏した場合:光デジタルケー ブルをつないでない場合) (FIA.J*)

*EIAJ(日本電子工業会)の測定方法に基づいて

**充電時間は充電式電池の使用状態により異なり

	ESPが OFFのとき	ESPが ONのとき	電池を火の中に入れないでくださ発熱、発火などのおそれがありま
H-DM2AA 約4時間充電**)	約12時間	約11時間	で、充電式電池や乾電池の'端子の を金属で接続しないでください。
C-DMAA 約4時間充電**)	約7時間	約6時間	性のボールペン、ネックレス、コ ヘアーピンなどと一緒に携帯、6
'ルカリ乾電池 R6SG 2本	約20時間	約18時間	ないでください。) • 乾電池と充電式電池の併用はした

他の併用はしないでく ださい。

ディスクテーブルのレンズには指を触れ ないでください。また、ホコリがつかな いように、ディスクの出し入れ以外はふ たを必ず閉じておいてください。 • 落としたり重いものを乗せたりしないで

ください。本機に強いショックを与えた り、圧力をかけたりしないでください。 ディスクに傷がついたり、本機の故障の 原因となることがあります。

• 本機に使われているレーザー光が目にあ

• 次のような場所に置かないでください。

くなど温度が非常に高いところ。

め切った自動車内(特に夏季)。

一ぐらついた台の上や傾いたところ

―風呂場など、湿気の多いところ。

ラジオやテレビの音に雑音が入るとき

• ACパワーアダプターでご使用中は、本

は、本機の電源を切って、ラジオやテレ

機を絶対に布などでくるまないでくださ

い。本機の内部および外部の温度が上が

り、思わぬ結果が発生することがありま

ディスクの取り扱いについて

本機では円形ディスクのみお使いいただ

けます。円形以外の特殊な形状(星型、

ハート型など)をしたディスクを使用す

ヘッドホンで聞くときのご注意

自転車やバイク、自動車などの運転中

は、ヘッドホンは絶対に使わないでくだ

さい。歩行中でも音量を上げすぎるとま

わりの音が聞こえなくなり危険です。と

くに、踏切や横断歩道では充分にご注意

耳を刺激するような大きな音量で長時間

続けて聞くと、聴力に悪い影響を与える

ことがあります。耳を守るため、音量を

ヘッドホンは、音量を上げすぎると音が

外にもれます。音量を上げすぎて、まわ

りの人の迷惑にならないように気をつけ

雑音の多い所では、音量を上げてしまいが

ちですが、ヘッドホンで聞くときはいつも

呼びかけられて返事ができるくらいの音量

別売りのヘッドホンで付属の

アラカルトヘッドホン(ステレオミニプラ

グ)をお使いください。マイクロプラグのも

付属のリモコンでは他のCDコンパクトブ

レーヤーを操作できないことがあります。

また、他機種に付属のリモコンでは本機の

レンズクリーニングキットKK-DM1(別売

り)を使ってクリーニングしてください。

キャビネットの汚れは

めますので使わないでください。

柔らかい布で空ぶきします。汚れがひどい

ときは、うすい中性洗剤溶液でしめらせた

ン、アルコールなどは表面の仕上げをいた

布でふいてください。シンナー、ベンジ

マイクロプラグ

レンズ

リモコンを使う場合は

上げすぎないように注意しましょう。

• まわりの人のことを考えて

を目安にしてください。

のは使えません。

ステレオミニプラグ

リモコンについて

操作はできません

お手入れ

レンズの汚れは

交诵安全のために

ください。

• 耳を守るために

ると、本機の故障の原因となることがあ

など磁気を帯びたところ。

-ホコリの多いところ。

―振動の多いところ。

ビから離してください

― 直射日光があたる場所や暖房器具の近

―ダッシュボードや直射日光下で窓を閉

一磁石やスピーカー、テレビのすぐそば

ACパワーアダプターについて 付屋のACパワーアダプターまたはAC E45L/AC-E45MA(別売り、国内用)/ AC-E45HG (別売り、海外用)をご使

用ください。これ以外のACパワーアダ

プターを使用すると、故障の原因となる

ことがあります。 極性統一形プラグ

• 電源コンセントから抜くときは、必ず ACパワーアダプターを持って抜いてく ださい。

充電式電池と乾電池について




このマークはニカド電池のリ サイクルマークです。

Ni-Cd

この製品には、二カド電池が使用できま す。二カド電池はリサイクルできる貴重な 資源です。 二カド雷池の交換および、 ご使 用済みの製品の廃棄に際しては、二カド雷 池を取り出し、金属部にセロハンテープな どの絶縁テープを貼って二カド電池リサイ クル協力店へご持参ください。

本機は、安全確保のため一般の充電式電池や 乾電池は充電できない構造になっています。



お買い求めの際は、必ず専用の充電式電池 専用充電式電池: NC-DMAA(2本組) NH-DM2AA(2本組)

詳しくは、お求めの販売店でご確認ください。

と'端子 (金属 コイン、 保管はし

本機の取り扱いについて

周波数特件 故障かな?と思ったら

20 Hz ~ 20,000 Hz +1 dB*

ライン出力(ステレオミニジャック) 1個

最大出力レベル 0.7 Vrms(47 kΩ)

推奨負荷インピーダンス 10 kΩ以上

ヘッドホン出力(ステレオミニジャック)1個

最大出力レベル 15 mW+15 mW

推奨負荷インピーダンス 16Ω

光デジタル出力(光ミニジャック)1個

発光波長 630 ~ 690 nm

• 充電式ニカド電池NC-DMAA

2本(付属): DC 2.4 V

2本(付属): DC 2.4 V

*日本電子機械工業会(EIAJ)規格による測定値

• 充電式ニッケル水素電池NH-DM2AA

単3形アルカリ乾電池2本(別売り)

外部電源ジャック 定格DC 45 V

AC 100 V雷源から使用可能

ACパワーアダプター(付属)を接続して

ワールドモデルはAC 100~240 V電源か

カーバッテリーコード(別売り)を接続し

約131.8 × 23.9 × 142.0 mm(幅/高さ/奥行き、

ご使用時 約310 g(充電式電池、ディスク、

最大突起部含まず、奥行きは傾斜部含まず)

約131.8 × 25.3 × 142.3 mm

リモコン付きヘッドホンを含む)

バッテリーキャリングケース(1)

サービス窓口•ご相談窓口のご案内(1)

仕様および外観は、改良のため予告なく変更する

リモコン付きヘッドホン(1)

ことがありますが、ご了承ください。

ACパワーアダプター AC-E45L

カーコネクティングパック CPA-8

接続コード RK-G129、RK-G134

アクティブスピーカー SRS-A21

光デジタルケーブル POC-5B.

POC-10AB, POC-15AB

ヘッドホン MDR-F848I P

充雷式雷池 NH-DM2AA

接続**コード** RK-G129HG

ングパック DCC-E26CP

充電式電池 NC-DMAA

POC-10B, POC-15B, POC-5AB

カーバッテリーコード DCC-E245

ACパワーアダプター AC-E45HG

カーコネクティングパック CPA-9

カーバッテリーコード付きカーコネクティ

国によって扱っているアクセサリーが違います。

くそ 製品上のCEマークはEU加盟国で販売されるもののみに有効です。

詳しくはお買い上げ店、サービス窓口、海外

ソニーサービス特約店にご相談ください。

カーバッテリーコード付きカーコネクティ

別売りアクセサリー

ングパック CPA-83U

国内、海外で販売

海外でのみ販売

キャリングケース(1)

ACパワーアダプター(1)

て自動車バッテリーから使用可能

最大出力レベル -21~-15 dBn

ワウ•フラッター

電源●その他

DC 3.0 V

ら使田可能

(幅/高さ/奥行き)

本体 約200 a

5°C ~ 35°C

充電式電池(2)

取扱説明書(1)

保証書(1

本体寸法

最大外形寸法

質量

動作温度

付属品

測定限界以下'

出力端子(雷源雷圧4.5 V時)

(EIAJ/16 Ω)

サービス窓口にご相談になる前にもう1度 チェックしてみてください。それでも具合 が悪いときはお買い上げ店またはソニー サービス窓口にご相談ください。

演奏が始まらない。または、ディ スクを入れても「no d! 5に」が

- ⇒ ディスクが汚れている、または大きな傷が ある。大きな傷がある場合は、ディスクを
- 取り換える。 ⇒ ディスクのラベル面を上にして入れる。
- ⇒ 結露している。ディスクを取り出して、そ のまま数時間置く
- → レンズが汚れている。
- ★本体、電池入れのふたをしっかり閉める。 → 充電式電池と乾電池を正しく入れる。

→ ACパワーアダプターをコンセントにしっ かり差し込む。

ジョグレバーの▶Ⅱを押すと 「00」が一瞬表示されて消える。 演奏が始まらない。 ⇒ 雷池の残量がない。充電式電池は充電する。

音が出ない、または雑音が聞こえる。 ⇒ プラグをしっかり差し込む。

乾電池はすべて新しいものに取り換える。

布でクリーニングする。 「HI dc In」表示が出ている。

→ プラグの先が汚れている。乾いた柔らかい

→ 付属のACパワーアダプターか別売りの ACパワーアダプターAC-E45L/AC-E45MA/AC-E45HGを使う。

→ カーバッテリーコードは、別売りアクセサ リーに記載されているものをお使いくださ

ボタンを押すと「Hold」が出る。

→ HOI D状態になっている。HOI Dスイッ チを矢印と逆の方向にずらし、HOLD機 能を解除する。

ボタンを押すと「Lo batt」が出

→ 充電式電池が消耗している。ACパワーアダ プターを接続し、充電式電池を充電する。 新しい乾電池と取り換える。

乾電池使用時の演奏時間が短い。

⇒ マンガン乾電池を使用している。アルカリ 乾電池を使う。 新しい乾電池と取り換える。

デジタル録音時に曲番が正しく

- 録音されない。 → MDまたはDATなどの機器側で正しく入れ 直す。
- → ステレオ機器につなぐICの項の録音手順 で録音する。

主な仕様

コンパクトディスクデジタルオーディオシ

取り込み方式 非接触光学式読み取り (半導体レーザー使用) レーザー

GaAlAs ダブルヘテロダイオード $\lambda = 780 \text{ nm}$ 回転数

約500 rpm ~ 200 rpm(ESP OFF時) 約1000 rpm~350 rpm(ESP ON時) エラー訂正方式 ソニースーパーストラテジー

(クロスインターリーブリードソロモン コード) 復号化(D/A) 1 bitクォーツ時間軸制御

English

▶ Disc Playing

and car battery.

1 Make connections

Close the lid.

② Adjust the volume

To stop play, press ■

To use the remote control

3 Play a CD.

Resume play after

Find the beginning

Find the beginning of

Find the beginning of

the succeeding tracks

Go forward quickly

*AMS = Automatic Music Sensor

Go backwards

quickly

and pause.

Find the beginning of Slide the jog lever

**These operations are possible during both play

If you press RPT/ENT (REPEAT/ENTER on

tracks continuously in the following order:

When using I◄
 : previous track →

→ second to last track

To remove the CD

the player) to display " 🖚 ", you can locate the

When using ►►: next track → next track

previous track first track → last track

You can do the operations shown in the above

table by using the buttons with the same

Remove the CD while pressing the pivot.

Notes on controlling the volume

Set the VOL (volume) control on the remote

control to the maximum. Then adjust the

volume on the player to the level that you

want to be the maximum volume of the

with the remote control

.. last track → first track → second track

the next track

(AMS*)

(AMS)

Playing a CD right away! A

If you want to play a CD right now, choose to

choices are the following three: rechargeable

Connect the supplied earphones with

firmly. Also connect the supplied AC

power adaptor does not fit the wall

Slide OPEN to open the lid.

Press the jog lever toward ►II.

(Press ►II on the player.)

The lever marked with $\blacksquare \blacksquare \blacksquare$ is the

jog lever. When you press or slide the lever

Do this

Press the jog lever

Press the jog lever

Slide the jog lever

Slide the jog lever

Slide the jog lever

toward ►► once

Slide and hold the

jog lever toward ▶▶I**

Slide and hold the

jog lever toward I◀◀**

toward ►►I

repeatedly*

toward ►

toward ►II

② Fit the CD to the pivot with the label

outlet, use the AC plug adaptor.

power adaptor to the DC IN 4.5 V jack of

your player and a wall outlet. If the AC

mote control to the \(\text{\cappa}/\text{REMOTE}\) jack

batteries, dry batteries (see "Power Sources"

use your player on house current. Other

As you read, refer to the illustrations in th Japanese corresponding text (labeled with 🗚

During play, the track number and the

Notes on display

elapsed playing time of the current track Between the tracks, the time to the

• When you press ►II (when RESUME is set

to OFF), the total number of the tracks in

the CD and the total playing time appear

beginning of the next track will appear with the "-" indication.

· During pause, the elapsed playing time of the current point flashes.

Notes on Handling CDs • To keep the CD clean, handle it by its

edge.Do not touch the surface. Do not stick paper or tape onto the CD.

· Do not expose the CD to direct sunlight or heat sources such as hot air ducts. Do not leave the CD in a car parked in direct

Playing tracks repeatedly (Repeat Play) B You can play track repeatedly in normal,

INTRO PGM, shuffle or RMS (Random Music Sensor) play modes. Repeat all the tracks or only one track.

To repeat all the tracks Press RPT/ENT (REPEAT/ENTER on the player) during play. appears.

To cancel repeat play, press RPT/ENT again.

To repeat a single track 1 Press RPT/ENT while the track you want repeat is playing.

2 Press P (play) MODE (PLAY MODE on the player) repeatedly until "1" appears. To repeat another track, slide the jog leve

toward I◀◀ or ▶▶I To cancel repeat play, press RPT/ENT again.

by scanning through the beginning of each 1 During play, press P MODE repeatedly

You can choose and play your favorite tracks

3 Press RPT/ENT while the track you want is playing. To skip the track, slide the jog lever toward ►►I or just wait for the next

After you have gone through the CD, "INTRO PGM" stops flashing and the tracks you have chosen play automatically.

selected tracks will be played. prevent accidental erasure, set the RESUME switch at the rear of the player to ON.

> To cancel INTRO PGM play, press P MODE until the play mode indication disappears from the display.

Playing tracks in random order (Shuffle Play) D You can play the tracks on a CD in random

The tracks play in random order To cancel shuffle play, press P MODE you want (RMS play) |E|

You can program up to 22 tracks to play in any order vou choose.

batteries). While you press and hold down ■ *RMS = Random Music Sensor

The track number and the playing order equipment K You can listen to the CD through other stereo equipment, or record a CD on a cassette tape or a MiniDisc. Refer to the instruction manual

3 Press RPT/ENT to program the track.

4 Repeat steps 2 and 3 to program the **5** Press the jog lever toward ►II.

"RMS" stops flashing and the tracks you have chosen play in the order you If you press ■, the program will be erased. To

switch at the rear of the player to ON. To cancel RMS play, press P MODE until

"RMS" disappears. To check the program

During progra Press RPT/ENT before step 5 During RMS play: Press P MODE repeatedly until "RMS"

flashes, then press RPT/ENT.

The ESP (Electronic Shock Protection

back in the event of a shock.

function minimize skipping by using a buffe

memory that stores music data and plays it

The new ESP^2 (ESP Squared) system uses a

read and store music data more efficiently

protection not found in traditional buffe

buffer memory. Use this function when

listening in a car or while walking.*

while jogging or running

The ESP indication appears

Press SOUND to select

in the display

To lock the buttons $\ensuremath{\mathbb{H}}$

To unlock, slide HOLD back

Press ESP.

providing a level of continuous skip

new DSP (Digital Signal Processor) which can

emory units. This decreases the frequence

of sound skipping and the need to utilize the

Although ESP² provides excellent protection

gainst skipping, it will not prevent skipping

To release the ESP function, press ESP again.

To enjoy more powerful bass sound

You can enjoy a powerful bass-boosted

MB (Mega Bass) or GRV (Groove). GRV is

You can lock your player against any

Slide HOLD in the direction of arrow

the player with the remote control.)

accidental operations. (You can still operate

When you press any button, "Ho! d" appears

Each time you press the button, the track numbers appear in the order you specified.

Using other functions To minimize skipping (ESP²) F

Playing only the tracks you want (INTRO PGM play) C

2 Press the jog lever toward ►II to start The player plays about the first 15 seconds of each track and "INTRO PGM" flashes faster.

To finish programming before going through he CD, press the jog lever toward 💵. The

If you press \blacksquare , the program will be erased. To

During play, press P MODE repeatedly, until 'SHUF" appears.

repeatedly until the play mode indication disappears from the display.

Playing tracks in the order

1 During play, press P MODE repeatedly until "RMS*" flashes.

on the player, connect the power source again. To make the beep sound again. connect it without pressing ■. 2 Slide the jog lever toward ◄ or ► to Connecting to other stereo

making connections, turn off each piece of equipment. When you connect the player to a stereo system, cassette recorder, radio cassette

recorder, etc., use the connecting cord

When you connect the player to a MiniDisc

recorder, DAT deck, etc., use the optical

Recording with optical digital

Record a CD on a MiniDisc, DAT, etc.

Press ►II on the player to start play

Press ►II again to pause.

want to record.

cording to the following procedure

3 Press ► to select the track you

4 Press ● (record) on the MiniDisc recorder

5 Press ►II on the player to release pause

• Connect the optical digital connecting cord

while the player is in stop mode.

digital connecting cord.

of the other equipment for details. Before

To turn off the beep

operate your player

You can turn off the beep that sounds as you

Disconnect the power source (AC power

adaptor, rechargeable batteries or alkaline

When you use a connecting cord, the SOUND

batteries for this player. You cannot use any other rechargeable batteries.

2 Insert two rechargeable batteries by matching the ⊕ and ⊖ to the diagram

3 Connect the AC power adaptor The indication "CHG" lights up. Charge for about 4 hours. (When the battery has been already

4 When fully charged, "CHG" disappears. Disconnect the AC power adaptor.

Take out the batteries in the proper way as illustrated inside the lid.

When to charge the batteries When the batteries become weak, indication appears in the display. If "Lo batt" appears in the display, charge the rechargeable batteries, because the batteries To keep the original battery capacity for a

When carrying the rechargeable batteries

batteries are used up (discharged).

Make sure to use the battery carrying case (supplied with the rechargeable batteries) If you carry the rechargeable batteries with a metal object, short circuit, smoke or fire may

long time, recharge the batteries when the

• This player is designed so that it cannot charge any other rechargeable batteries or dry batterie for safety reasons • Charging time varies depending on how the rechargeable battery is used.
•If the battery is new or has not been used for a long time, it may not be charged completely

batteries. Do not use any other rechargeable

Using dry batteries N

Insert the batteries properly in the same way a the rechargeable batteries.

open the lid of the battery compa 2 Insert two LR6 (size AA) alkaline

batteries by matching the \oplus and \ominus to the diagram inside the battery compartment and close the lid.

• Do not use manganese batteries for this player

1 Disconnect the AC power adaptor and

To take out the dry batteries Take out the batteries properly in the same way as the rechargeable batteries

When to replace the dry batteries When the batteries become weak, indication appears in the display. If the batteries are used up, "Lo batt" appears i the display. Replace all the batteries with new

• Do not mix new batteries with old ones · Do not mix rechargeable batteries with dry Do not use different types of batteries together

time, remove them. · If the battery leakage occurs, wipe off any new batteries

(FIAJ*)

NH-DM2AA 12 11 (charged for about 4 hours**) NC-DMAA

Two alkaline batteries 20 18 LR6SG

▶Power Sources

batteries M

Using rechargeable

Remote contro

(stop) button

►II: play/pause

SOUND button

ESP button

I◀◀ / ▶▶I: AMS/search

VOL (volume) control

P (play) MODE button

RPT (repeat)/ENT (enter) button

You can turn and change the angle of the

Charge the rechargeable batteries before using them for the first time You can use the NC-DMAA rechargeable batteries and the NH-DM2AA rechargeable

1 Open the lid of the battery compartmen

inside the battery compartment and clos

charged, "CHG" and a flash.)

• If you record without pausing the player, some CD may have problem with recording the first To take out the rechargeable track number correctly.
• SOUND function works on output from the O/REMOTE jack but does not work on optical digital output from the LINE OUT (OPTICAL)

When you use an optical digital connecting cord, the ESP function will be disabled. Playing a CD in a car

You cannot use the car mount plate for this When you use the player in a car, install it securely in a location which does not interfere

vour driving. To connect your player to a car cassette deck you need the following accessories: Car battery cord DCC-E245 and Car

nnecting pack CPA-8/CPA-9

Refer to the instruction manual of each

You can use your player in a car by

connecting it to the car cassette deck.

Switched ignition function (when using the car battery cord) With this feature, your player sto automatically when you turn off the engine of

the car. (This function is not possible with

some cars depending on the model.)

Parts identification L Main unit

HOLD switch

OPEN switch

SOUND button

To protect your hearing (AVLS) I System) function keeps down the maximum volume to protect your ears

The AVLS indication appear

Set AVLS to LIMIT

Set RESUME to ON.

stopped the CD (Resume Play) J Normally, every time you stop and pla playing starts from the beginning of the CD. listen to from the point at which you last turned off the player

To cancel resume play, set RESUME to OFF

PLAY MODE button ESP* button

►II (play/pause) buttor

REPEAT/ENTER button

AVLS*** switch (rear)

RESUME swich (rear

Idd /▶►I (AMS**/search) buttons

13 DC IN 4.5 V jack (external power intput

To resume playing from the point you

LINE OUT (OPTICAL) jack VOLUME control 16 (headphones)/REMOTE jack *Electronic Shock Protection

**Automatic Music Sensor *Automatic Volume Limiter System

til you charge and discharge it several tim · If the battery life becomes shorter by about half replace it with Sony NH-DM2AA rechargeabl atteries or Sony NC-DMAA rechargeable

· Do not charge the dry batteries

•When the batteries are not to be used for a long

Battery life (approx. hours)

(charged for

*Measured value by the standard of EIAJ

*Charging time varies depending on how the

deposit in the battery compartment, and insta

ESP function

(Electronic Industries Association of Japan (When you use the player on a flat and stable place: When you do not use the optical digita